



## **LOCATOR SYSTEM**

The Locator Picture Hanging System has been specifically designed to be an extremely functional way to hang pictures and other objects that are best displayed with a wall hanging system.

When installed, the Locator fixing screws are hidden from view. The rail snaps onto a horizontal or sloped row of nylon bushes which are screwed directly to the wall. This is particularly useful if the rail has to be fixed to a hollow partition because some of the bushes can be affixed to the vertical studwork. Although the bushes can be fixed anywhere on the horizontal line, they must support the whole length of the rail.

## **INSTALLATION INSTRUCTIONS**

- Determine whether the wall is made of Masonry or Plasterboard.
- FOR PLASTERBOARD – Locate the studs using a stud finder (quite cheap from a hardware store). These are usually at 450mm or 600mm centres.
- FOR PLASTERBOARD - make sure you are screwing into the studs and gently into the plasterboard at the centre point between the studs. If there is no available stud at the end of your run use a wallmate. You may use wallmates at any point to increase the strength of the rail fixing.
- FOR MASONRY - drill 6.5mm holes using a hammer or rotary hammer drill at 300-400mm gaps, use green wall plugs.
- Make marks 10mm below the ceiling or cornice if you aim to have the rail tight to the ceiling/cornice. Else draw a horizontally level pencil line where you would like your rail.
- Screw in nylon bushes and cut rail to fit using a hacksaw – aim to use uncut ends together at joins or else file ends straight.
- Slide the rail onto the end bush firmly press onto the bushes else tap with a rubber mallet.
- Use connectors to join the rail
- Place end-caps on any visible ends

Note: If installing a sloping rail, take care to stop rail sliding off the bushes by either butting it up against a wall or placing a screw through the rail at the lower end.